

Lights and Fans

All lights and fans must be in workable condition prior cargo operation and maintained thereafter.

Fans must be maintained according to manufactures instruction to give sufficient air exchange per hour to obtain healthy air for safe working condition.

